



REF #	PART #	PART NAME	REF #	PART #	PART NAME	REF #	PART #	PART NAME
1	20470327	Front panel assembly	25	20474920	Igniter cover	49	20474975	L-shaped hose
2	20470360	Top plate	26	20478026	Fuel nozzle	50	20470261	Inlet hose
3	20470377	Operation panel	27	20479885	Outside nozzle gasket	51	20474925	Oil catch
4	20478373	Thermistor	28	20479883	Fuel nozzle gasket	52	20470220	Screw 4I
5	20475535	Power supply cord	29	17185327	Window gasket	53	20455862	Screw S2
6	20470346	Cabinet assembly	30	17185314	Peep window	54	20474048	Screw B
7	20470351	Rear guard (L & R)	31	20479521	Igniter guide gasket	55	20476452	Screw B2
8	20470350	Rear guard top	32	20470337	Blower motor assembly	56	20470353	Screw 4P
9	20479840	Circulation air filter	33	20479574	Blower motor gasket	57	20470254	Screw 4J
10	20470329	Drip tray	34	20470212	Main circuit board	58	20470355	Screw 4Q
11	20470352	Leveler fuel pipe	35	20477414	PCB support	59	20478355	Screw 1Z
12	20479568	Air joint gasket	36	20470206	High limit switch	60	20470666	Screw 4C
13	20479531	Relief spring	37	20470319	Fuel pump	61	17185352	Flame rod gasket
14	20479530	Pressure relief plate	38	20479886	Draft tube	62	20479866	Air damper
15	20479591	Relief gasket	39	20470341	Fuel pipe assembly	63	20478550	Fuel inlet strainer
16	20479844	Heat exchanger	40	20470234	Fuel sump	64	20475551	Drain screw with O-ring
17	20478343	Burner ring	41	20479803	Air intake fan	65	20475552	Strainer gasket
18	20479893	Heat exchanger gasket	42	20474171	Circulation fan	66	20470375	Ribbon cable
19	20479842	Burner assembly	43	20479869	Circulation fan motor	67	20470678	Fuse 1 (5A)
20	20479894	Burner gasket	44	20470366	Nut L	68	20470679	Fuse 2 (10A)
21	20479811	Primary flame rod	45	20474039	Insulator A	69	20470255	Insulating cloth cover
22	20470273	Burner thermistor	46	20479891	Flue pipe	70	20470395	Instruction manual
23	20470218	Igniter	47	20474977	Hose band	71	20470399	Carton
24	17187582	Igniter gasket	48	20479884	Bent joint			