



Toyostove Laser 30 or Oil Miser 23 Lockout on “EE22”

WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.

The Toyostove Laser 30 has a 20-minute retention display feature (clock/temperature Settings) on the operation panel in the event of a power loss to the heater. This feature will also affect the EE-22 code as it will continue to display even if the heater is unplugged.

To erase the EE-22 error code, there are two procedure options:

1. Unplug the heater for at least 20-30 minutes.
2. Unplug the heater and short circuit (for one second) across the bars marked BU5V (JX11) and OV (J12) located on the face of the main circuit board.

**** IMPORTANT ****

1. **THE HEATER MUST BE UNPLUGGED FROM THE POWER SOURCE FOR EITHER OPTION.**
2. All other error codes can be erased by pushing the on/off power switch on the operation panel.