



# Toyostove Laser 30 or Oil Miser 23 Lockout on “EE22”

---

## **WARNING**

*Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.*

The Toyostove Laser 30 has a 20-minute retention display feature (clock/temperature Settings) on the operation panel in the event of a power loss to the heater. This feature will also affect the EE-22 code as it will continue to display even if the heater is unplugged.

### **To erase the EE-22 error code, there are two procedure options:**

1. Unplug the heater for at least 20-30 minutes.
2. Unplug the heater and short circuit (for one second) across the bars marked BU5V (JX11) and OV (J12) located on the face of the main circuit board.

### **\*\* IMPORTANT \*\***

1. **THE HEATER MUST BE UNPLUGGED FROM THE POWER SOURCE FOR EITHER OPTION.**
2. All other error codes can be erased by pushing the on/off power switch on the operation panel.