



Cleaning the Flue Assembly

WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.

Reminder: When performing any form of maintenance or repair on a Laser vented heater that has been in service for more than one season it is advisable to check and clean - if necessary - the flue assembly.

This includes:

- FLUE PIPE
- EXHAUST ELBOW (BENT JOINT)
- EXTENSION PIPE EXHAUST PIPES.

Wash the parts with soap and water if they contain deposits of soot.

