

## How to use the De-Coking Rod

### Applies to models: NordicStove: All Models

A de-coking rod removes deposits and obstructions within the fuel nozzle tube. Over time, soot and other particles can likely build up inside the tubing, impeding the oil flow into the burner.

To clean the fuel nozzle tube, rotate the rod (pictured below) and move it back and forth reciprocally.



Figure 1: De-coking Rod

### **WARNING:**

If the NordicStove is in use, the de-coking rod will be HOT.

Use gloves to turn the de-coking rod.

### **WARNING**

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.