

## Cleaning the Flue

**Applies to models:**  
**Toyotomi Laser Heaters: All Models**

Reminder: When performing any form of maintenance or repair on a Laser vented heater that has been in service for more than one season it is advisable to check and clean - if necessary - the flue assembly.

This includes:

- FLUE PIPE
- EXHAUST ELBOW (BENT JOINT)
- EXTENSION PIPE EXHAUST PIPES.

Wash the parts with soap and water if they contain deposits of soot.



### **WARNING**

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.