

Fuel Oil Line Parts List, Tank to Heater

Applies to Models: All Toyotomi Toyostove Models

Starting at the tank, you will need:

1. each Fuel tank valve kit (R.E.E. part# FTKIT) This kit contains:
 - (1) each $\frac{3}{4}$ " Gatevalve (R.E.E. part# PHAN-GATEVALVE)
 - (2) each $\frac{3}{4}$ " x 2" Nipple (R.E.E. part# PHAN-NIPPLE)
 - (3) each 1" x $\frac{3}{4}$ " Bushing (R.E.E. part# PHAN-1X3/4BUSH)
 - (1) each 1" x $\frac{3}{8}$ " Bushing (R.E.E. part# PHAN-1X3/8BUSH)
 - (1) each $\frac{3}{8}$ " Flare Nut (R.E.E. part# PHAN-FLARENUT)
 - (1) each $\frac{3}{8}$ " x $\frac{3}{8}$ " Brass FLxMIP Union 408 (R.E.E. part# PHAN-UNION)



WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.

- (1) each Water Block Fuel Filter (R.E.E. part# FF, includes Golden Rod 496 Water Block Filter, Water Block Filter Element 496-5, 15 micron)



- (1) each Fuel Filter Fittings (R.E.E. part# FFF)



WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.

1. each $\frac{3}{8}$ " shutoff valve (R.E.E. part# 1WME1)



2. each $\frac{3}{8}$ " Flare nuts (R.E.E. part# PHAN-FLARENUT)



$\frac{3}{8}$ OD ($\frac{1}{4}$ " ID) type L copper fuel line (R.E.E. part# CFL60FT, 60ft. coil)

WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.



When replacing an existing Toyostove, a new flue must be installed.

Installation Kit (R.E.E. part# 20478786) includes new flue and installation hardware.



If the distance from the top of the tank to the bottom of the unit is more than 8 ½ feet, a pressure reducing valve is required (R.E.E. part# PRV, 3/8" connection, 2 psi.)

Fuel line must not have any ups and downs (traps air) or downs and ups (traps water, creating an ice plug in sub-freezing temperatures). The fuel line should have a steady downward slope from the tank to the unit.

WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.



6637 Arctic Spur Rd. Anchorage, AK 99518
P. 907.278.7441 / 800.770.7330 (toll-free)
F. 907.868.1766

WARNING

Rural Energy Enterprises, Inc. does not accept liability for the improper use of this information. Installation, service, and maintenance of heating equipment should be performed by a qualified technician. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life.